# HIKVISION

# Interactive Flat Panel

**User Manual** 

# **Legal Information**

#### **About this Document**

- This Document includes instructions for using and managing the Product. Pictures, charts, images and all other information hereinafter are for description and explanation only.
- The information contained in the Document is subject to change, without notice, due to firmware updates or other reasons. Please find the latest version of the Document at the Hikvision website (<a href="https://www.hikvision.com">https://www.hikvision.com</a>).
   Unless otherwise agreed, Hangzhou Hikvision Digital Technology Co., Ltd. or its affiliates (hereinafter referred to as "Hikvision") makes no warranties, express or implied.
- Please use the Document with the guidance and assistance of professionals trained in supporting the Product.


#### **About this Product**

- This product can only enjoy the after-sales service support in the country or region where the purchase is made.
- If the product you choose is a video product, please scan the following QR code to obtain the "Initiatives on the Use of Video Products", and read it carefully.



## **Acknowledgment of Intellectual Property Rights**

- Hikvision owns the copyrights and/or patents related to the technology embodied in the Products described in this Document, which may include licenses obtained from third parties.
- Any part of the Document, including text, pictures, graphics, etc., belongs to Hikvision. No part of this Document may be excerpted, copied, translated, or modified in whole or in part by any means without written permission.
- **HIKVISION** and other Hikvision's trademarks and logos are the properties of Hikvision in various jurisdictions.
- Other trademarks and logos mentioned are the properties of their respective owners.



HDMI Trade dress and the HDMI Logos are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.

#### **LEGAL DISCLAIMER**

• TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THIS DOCUMENT AND THE PRODUCT DESCRIBED, WITH ITS HARDWARE, SOFTWARE AND FIRMWARE, ARE PROVIDED "AS IS" AND "WITH ALL FAULTS AND ERRORS". HIKVISION MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION, MERCHANTABILITY, SATISFACTORY QUALITY, OR FITNESS FOR A PARTICULAR PURPOSE. THE USE OF THE PRODUCT BY YOU IS AT YOUR OWN RISK. IN NO EVENT WILL HIKVISION BE LIABLE TO YOU FOR ANY SPECIAL, CONSEQUENTIAL, INCIDENTAL, OR INDIRECT DAMAGES, INCLUDING, AMONG OTHERS, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, OR LOSS OF DATA, CORRUPTION OF SYSTEMS, OR LOSS OF DOCUMENTATION, WHETHER BASED ON BREACH OF CONTRACT, TORT (INCLUDING NEGLIGENCE), PRODUCT LIABILITY, OR OTHERWISE, IN CONNECTION WITH THE USE OF THE PRODUCT, EVEN IF HIKVISION HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES

OR LOSS.

- YOU ACKNOWLEDGE THAT THE NATURE OF THE INTERNET PROVIDES FOR INHERENT SECURITY RISKS, AND
  HIKVISION SHALL NOT TAKE ANY RESPONSIBILITIES FOR ABNORMAL OPERATION, PRIVACY LEAKAGE OR OTHER
  DAMAGES RESULTING FROM CYBER-ATTACK, HACKER ATTACK, VIRUS INFECTION, OR OTHER INTERNET SECURITY
  RISKS; HOWEVER, HIKVISION WILL PROVIDE TIMELY TECHNICAL SUPPORT IF REQUIRED.
- YOU AGREE TO USE THIS PRODUCT IN COMPLIANCE WITH ALL APPLICABLE LAWS, AND YOU ARE SOLELY RESPONSIBLE FOR ENSURING THAT YOUR USE CONFORMS TO THE APPLICABLE LAW. ESPECIALLY, YOU ARE RESPONSIBLE, FOR USING THIS PRODUCT IN A MANNER THAT DOES NOT INFRINGE ON THE RIGHTS OF THIRD PARTIES, INCLUDING WITHOUT LIMITATION, RIGHTS OF PUBLICITY, INTELLECTUAL PROPERTY RIGHTS, OR DATA PROTECTION AND OTHER PRIVACY RIGHTS. YOU SHALL NOT USE THIS PRODUCT FOR ANY PROHIBITED END-USES, INCLUDING THE DEVELOPMENT OR PRODUCTION OF WEAPONS OF MASS DESTRUCTION, THE DEVELOPMENT OR PRODUCTION OF CHEMICAL OR BIOLOGICAL WEAPONS, ANY ACTIVITIES IN THE CONTEXT RELATED TO ANY NUCLEAR EXPLOSIVE OR UNSAFE NUCLEAR FUEL-CYCLE, OR IN SUPPORT OF HUMAN RIGHTS ABUSES.
- IN THE EVENT OF ANY CONFLICTS BETWEEN THIS DOCUMENT AND THE APPLICABLE LAW, THE LATTER PREVAILS.
- © Hangzhou Hikvision Digital Technology Co., Ltd. All rights reserved.

# **Preface**

# **Applicable Models**

This manual is applicable to Interactive Flat Panel.

# **Symbol Conventions**

The symbols that may be found in this document are defined as follows.

Symbol	Description		
Note	Provides additional information to emphasize or supplement important points of the main text.		
Indicates a potentially hazardous situation, which if not avoide could result in equipment damage, data loss, performan degradation, or unexpected results.			
Indicates a hazard with a high level of risk, which if not avoided, we result in death or serious injury.			

# **Contents**

Chapter 1 Introduction	
Chapter 2 Operation and Maintenance Precautions	2
2.1 Use of Power Cable	
2.2 Cleaning and Maintenance	
Chapter 3 Connection and Installation	4
3.1 Precautions for Installation	4
3.2 Appearance and Interfaces	4
3.2.1 Front Panel and Interfaces	4
3.2.2 Interfaces on Main Board	6
3.2.3 Connection to Personal Computer (PC)	6
3.3 Internal Computer Installation	7
3.4 Mounting	8
Chapter 4 Startup and Shutdown	
4.1 Device Startup	
4.1.1 Installed Without a Computer Box	
4.1.2 Installed with a Computer Box	
4.2 Eco Mode	
4.3 Shutdown	
Chapter 5 Menu Operations	
5.1 Basic Operations	
5.2 System Bar	
5.3 Input Source	
5.4 Network	
5.5 Control Menu	
5.5.1 Note	
5.5.2 Screenshot	
5.5.3 Vote Machine	
5.5.4 Random Select	
5.6 Camera Functions	
5.6.1 Camera	
5.6.2 Video	
5.6.3 Settings	
Chapter 6 System Settings	26
6.1 Network Settings	
6.1.1 Wired Network Settings	
6.1.2 Wireless Network Settings	
6.1.3 WLAN Hotspot Settings	
6.2 Display Settings	
6.3 Audio Settings	
6.4 Language and Input Settings	
6.5 Date and Time Settings	
6.6 Application Management	
6.7 Bluetooth	
6.8 Auxiliary Functions	
6.8.1 Intelligent Temperature Control	33
6.8.2 Smart Remote Control	34

# Interactive Flat Panel • User Manual

6.9 Advanced Settings	35
6.10 User Settings	39
6.11 Device Information	40
6.12 Negative Screens	40
Chapter 7 Intelligent Applications	
7.1 FileBrowser	
7.2 Browser	43
7.3 Whiteboard	43
7.3.1 Toolbar Basic Operation	44
7.3.2 More Tools	
7.3.3 Manage Whiteboard	49
7.3.4 Save Whiteboard	
7.3.5 Share Whiteboard	
7.3.6 More Functions	51
7.4 WonderCastServer	52
7.4.1 NFC Screen Mirroring	52
7.4.2 Other Screen Mirroring	
7.5 System Pre-Installed Applications	
Chapter 8 Appendix A FAQs	

# **Chapter 1 Introduction**

The Interactive Flat Panel (hereafter referred as 'the device') integrates functions of computers, projectors, interactive whiteboards, sound boxes, advertising machines, and so on. The device is empowered by multiple technologies like 4K display, infrared touch, human-machine interaction, multi-media information processing, and network transmission, providing users with various features such as writing, annotating, multi-screen sharing, and remote video call (optional).

The device is mainly used for events including remote video Interactives, trainings and guidance, medical consulting, and others in places of offices, meeting rooms, multi-media classrooms, exhibition halls, and so on.

#### **Key Features**

- Ultra HD display with up to 3840 × 2160 resolution of input signal available.
- 20px ultra fine writing, and 2 mm diameter recognizable with the precision of 1 mm.
- Supports USB 3.0.
- Built-in Wi-Fi realizes screen mirroring without any cable connection.
- Built-in interactive whiteboard system allows annotating and sharing by QR code.
- Looping-out display available.
- Various audio and video interfaces for device access.
- Built-in network switch module saves a network switch.
- Built-in Android system provides kinds of applications.
- Compatible with OPS/OPS-C devices, realizing smooth switch between built-in systems.
- Ultra-thin design with aluminum profile frame.
- Recommendation for healthy use of the monitor (to prevent eye fatigue): It is recommended
  that users do not start at the screen for a long time, and take a rest occasionally.
  - After staring at the screen for more than 1 hour, you can relax your eyes by watching the distant scenery;
  - After staring at the screen for more than 1 hour, you can relax your eyes by doing eye
    movements.

# Chapter 2 Operation and Maintenance Precautions

The LCD panel on the device is made by high-precision technology. However, tiny spots on the screen that are always or never lit may be observed, or when observed from side, the color and brightness may appear to be uneven. Yet the above phenomena are common among LCD displays rather than faults and will not affect the performance of the device.

Not all blue lights are harmful. What is really harmful is blue light with a wavelength between 415 nm and 455 nm, while contrarily blue light between 480 nm and 500 nm is beneficial to the human body because it can help to regulate human body's biological rhythm in some way. Hikvision's low blue light technology is based on this fact. By adjusting the main blue peak of the LED, the energy of this band is reduced basically, thus the proportion of harmful blue light the hardware emits is effectively reduced. At the same time, by adjusting the design of the panel color film, Hikvision independently develops the NiceBlue module, which can still ensure the ultimate perfect picture quality in terms of color management, achieving good performance of both visual protection and display effect.

- Our company is not responsible for any fault caused by third-party when operating the device and other failure or damage incurred.
- Do not operate the device in an environment of dust, high humidity, or oil and steam contacting to avoid the risk of fire and damage.
- Do not place the device under direct sunlight or near strong light source.
- Do not place the device near other equipment with strong radiation.
- Do not expose the device to rain or humid environment.
- Do not place the device on unstable or unsafe surface. Avoid strong impact, vibration or vibration.
- Do not operate the device near heating device or place of high temperature to avoid the risk of fire.
- After moving the device from low temperature environment to high temperature environment, please do not turn on the device immediately and wait for the condensation to evaporate.
- Do not insert any object into the device.
- Do not place heavy objects upon the device.
- The device and its accessories are subject to change without prior notice.
- The fragile materials of the display are vulnerable to falling and impact. Please hold with care.
- Improper operations during debugging and operating may cause damage to the device.
- Scratching or knocking the device with hard objects is strictly forbidden. Do not frequently turn on/off the power of the device when operating to avoid the risk of damage and faults.

• If smoke, odor or noise rise from the device, turn off the power at once and unplug the power cable, and then please contact the service center.

## 2.1 Use of Power Cable

- If the power cable is damaged or failed, contact service center. Make sure the power supply is properly grounded and matches the requirements specified by the plate on the shell.
- Do not expose the device to rain or humid environment. Disconnect power plug and antenna in thunderstorm weather.
- If the device will not be used for a long time. Shut down the power of the device and disconnect the power supply.
- Electric discharge may last for a short period of time after the power is shut down. Please wait for two minutes after the power shut down to operate the device.
- Only use the original power cable delivered with the device. Contact authorized dealer to purchase power cable with same specifications.
- Make sure the power supply is grounded.
- Do not let dust or metal attachment adhere to the power plug and socket.
- Do not modify the cable in any form.
- Do not place heavy object on the cable.
- Keep the cable away from heat.
- Do not disconnect the power plug by pulling the cable.
- Keep the power cable away from physical or mechanical damage.
- The cable is applicable only to the Interactive Display. Do not use it on other devices.

# 2.2 Cleaning and Maintenance

- The hole on the rear shell is for heat dissipation. Do not pour or spray liquid to the rear shell or use wet cloth for cleaning.
- Disconnect the power plug before cleaning.
- Do not display images with high brightness on the screen for too long.
- Use a dry, soft and dust-free cloth to clean the device.
- Contact service center for internal cleaning.
- Proper maintenance can avoid certain early-stage failures.
- Clean the device on a regular basis to make the device look new.
- Do not clean the device with water, spray cleaner or industrial chemical reagent. Prevent foreign matters from entering the device.
- Contact qualified service personnel for device maintenance. If the device is damaged, please contact our company, do not carry out unauthorized maintenance.

# **Chapter 3 Connection and Installation**

## 3.1 Precautions for Installation

- Clean the device screen and back before installation for best performance.
- For safety, only use the wall mount or base provided by the manufacturer.
- Contact professional staff for wall mounting.
- Check the accessories before the installation. Contact the dealer if anything is missing.
- Do not install the device too tight. Otherwise the screen may be distorted.
- Mount the device on load-bearing wall.
- Place the device on a stable surface or fix the device steadily on the wall.
- Install the device near an available AC power socket for easy power connection. Use the same ground cable with other devices to prevent signal interference.
- Do not place the device near mechanical vibration source.
- Do not place the device in an environment where insects have easy access.
- Do not let the device face the air conditioner directly to avoid condensing.
- Do not place the device in strong electromagnetic field to avoid radio interference.

# 3.2 Appearance and Interfaces

## 3.2.1 Front Panel and Interfaces

The interfaces of Interactive Flat Panel are shown as followed.

# $[]i]_{Note}$

- Interfaces of the device vary from different types.
- The following description is from the direction facing the screen.




Table 3-1 Panel Description

No.	Description	No.	Description
1	Power supply interface 100 to 240 VAC	2/3	USB 3.0
4	Touch-USB interface supports connecting an externally laptop without driver program.	5	HDMI IN
6	Type-C interface supports DP, USB 2.0 and charging functions.	7	Environmental light sensor
8	NFC Operations refer to <b>7.4.1 NFC</b> Screen Mirroring.	9	<ul> <li>Power button</li> <li>Short press to turn to power-saving status.</li> <li>Press and hold to turn on or turn off the device.</li> </ul>
10	Lan Port × 2	11	Serial Port

## 3.2.2 Interfaces on Main Board




Figure 3-2 Main Board's Interfaces

Table 3-2 Main Board Description

No.	Name	Description	No.	Name	Description
1	SPDIF	Transmit digital audio	2	Line OUT	Audio output interface
3	Line IN	Audio input interface	4	VGA IN	Video devices connection interface
5	TYPE-C	Type-C interface	6	DP IN	Display input interface
7	TOUCH-USB 2	Peripheral touch interface	8	HDMI IN 2	HDMI 2 input interface
9	TOUCH-USB	Peripheral touch interface	10	HDMI IN 1	HDMI 1 input interface
11	USB	USB interface	12	MULTI- USB 2	Multi-functional USB interface
13	MULTI-USB 1	Multi-functional USB interface	14	HDMI OUT	HDMI output interface

# 3.2.3 Connection to Personal Computer (PC)

The connection of PC and the device is shown as below, front HDMI IN and Touch-USB combination works normally when screen is locked.

The device must be disconnected from power supply before installation or disassembly.




Figure 3-3 Connect to PC



- The Touch-USB interface is needed only when the user needs to touch operate the external PC on the device.
- Use high quality signal cable less than 10 meters in length for high HDMI signal transmission quality.
- USB cable is not contained in the product. Please purchase USB cable with Type-A connector to Type-B connector.

# 3.3 Internal Computer Installation




Figure 3-4 Internal Computer Installation

The computer box is installed at the side slot of the device. When installing the box, make sure its ventilation hole is facing the same direction with the rear panel as shown above. Fasten the screws to fix the box into position.



- The computer is an optional accessory.
- To avoid potential device damage, the computer box can be removed only after the device is disconnected from power.

# 3.4 Mounting

The device can be installed with wall mount or mobile mount, as shown below.

## Note

The accessories for wall mounting and mobile mounting are different. Do not mix them up.

## **Wall Mounting**




Figure 3-5 Wall Mounting Rear View




Figure 3-6 Wall Mounting Side View

# **i** Note

The wall mounting is mobile horizontally. Please leave a space no less than 6 cm at each side (or 12 cm at one side), and 5 mm at the top and bottom for maintenance service.

# **Mobile Mounting**




Figure 3-7 Mobile Mounting

# Chapter 4 Startup and Shutdown

# 4.1 Device Startup

## 4.1.1 Installed Without a Computer Box

- Step 1 Connect the device to power supply.
- Step 2 Turn on the power switch, and the power indicator on the front panel will turn red.
- Step 3 Push the power button on the front panel to start up the device, the indicator will turn blue.

## 4.1.2 Installed with a Computer Box

Install the box when the device is disconnected from power and turn on the power switch after the installation is finished. During the startup, the power indicator of the box will turn red and the fan will start. After a beep sound, the power indicator will turn green and the computer is switched on. Meanwhile, the power indicator on the front panel will turn blue which means the device is switched on.

## 4.2 Eco Mode

#### **Entering Eco Mode**

Press the power button on the front panel to turn off the screen and enter Eco Mode.

#### Waking up the Device

Four ways to wake up the device:

- Press the power button on the front panel.
- Press the power-off button on the remote control.
- Touch anywhere on the screen twice.
- Say "Xiaohai, Xiaohai" to wake up the screen.

## 4.3 Shutdown

- If the device is not installed with a computer box or the computer box is shut down, directly switch off the power to shut down the device.
- If the device is installed with a computer box which is powered on, tap **Start** and choose **Shutdown**, or press the power button on the computer box to shut it down (press and hold the power button to force shutdown). Then switch off the power to shut down the device.



Switching off the power of the device directly leads to force shutdown of the computer box. Next time the device starts up, Windows may enter error recovery mode and screen touch will be disabled. In this case, you need to connect a mouse and a keyboard to the device.

• Press and hold the power-off button on the remote control.

# **Chapter 5 Menu Operations**

# **i** Note

Software interfaces and functions may vary with device models. All pictures in this manual are for illustration purpose only.

Turn on the device and go to the main page. The shortcut menu is displayed at the bottom of the screen.




Figure 5-1 Main Page

# **i** Note

Press and hold the icons of applications on the main page to realize the following operations:

- Move applications cross screen.
- Open the application in the form of a window.
- Merge applications into folders with other applications.

# 5.1 Basic Operations

Functions of the shortcut icons are described below.



Table 5-1 Shortcuts Description

No.	Function	No.	Function
1	Tap to hide the menu bar at the bottom.	6	Tap to check or clear all the apps of processes.
2	Tap to return to the previous page.	7	Tap to configure network parameters and hotspot.
3	Tap to select the input source.	8	Tap to configure brightness and volume.
4	Tap to check all the applications.  Press and hold to move the selected application to display in split-screen mode or window mode.	9	Tap to open the control menu.
5	Tap to return to the main page.		

# **i** Note

Up to 20 pens are allowed when lines with angled stroke is disabled, while only one when enabled. After the bottom bar menu is hidden, it can be called out through.

Figure 5-3 Call Out Bottom Bar

# 5.2 System Bar

Press and hold the area of system bar to modify the layout of apps in the system bar.



Figure 5-4 Layout of System Bar

Click **Customize**, and move an icon to adjust its position.



Figure 5-5 Customize the Layout of System Bar

# 5.3 Input Source

Tap the icon of input source at the bottom, and set the input source of the device. **System, HDMI 1, HDMI 2, Type-C, DP,** and **VGA** are available.

## 5.4 Network

Set the detailed parameters of wired network, wireless network, and WLAN hotspot. Refer to *Network Settings* for more details.

## 5.5 Control Menu

Tap at the bottom to show the control menu and configure the following operations as required.



Figure 5-6 Control Menu

Table 5-2 Control Menu Descriptions

Tool	Description
Note	Take annotations on the current page.
Camera	Open the camera bound with the device.
Screenshot	Capture the current page.
Calculator	Enable the built-in calculator.
Stopwatch	Measure the amount of time.
Countdown	Count seconds backward to zero.
Voting Machine	Set vote settings to vote.
Random Select	Set number of options to select one randomly.
Record Screen	Record the screen as a video.
Lock Screen	Tap to enable touch lock, and no touch operation on the locked page is available. Tap the lock and exit, the touch function will return to normal.
File Transfer	Transfer files.
Virtual Remote Controller	Enable the virtual controller. The hovering display remote control menu supports up, down, left, right, confirm, return and home buttons, and the hovering virtual remote control position can be moved.
Freeze Screen	Freeze the current page.
Spotlight	Tap to enable an aperture. The brightness and the size can be adjusted.
Magnifier	Tap the Magnifier. Then touch the screen to see a zooming circle and move to see details. The size of the circle can be adjusted.
Metronome	Tap to see the Metronome. After tapping the start button, beat can be heard. The notes and beat can be adjusted.
Calendar	Check the date information.
Piano	A virtual piano tool.
Black Screen	Tap to turn off the screen.

# 5.5.1 Note

Go to lacktriangle Note to take notes. You can add notes anywhere on the page by touching and moving on the screen.




Figure 5-7 Take Notes

Table 5-3 Icon Descriptions

Icon	Description
L	Tap to adjust pen color and size to write.  Enable angled stroke or not. Tap to have lines with angled stroke, and tap to have lines without angled stroke.
<b>♦</b>	Tap to erase the desired notes.
	Tap to clear all the notes.
6	Tap to save the current page.  Generate QR code of notes when flat panel connects to the Internet or the LAN. Terminal devices with Internet access or in the same LAN with the Interactive Flat Panel can scan the QR code to download notes.
×	Tap to exit note.
»/«	Tap to collapse/expand note toolbar.

# **i** Note

Up to 20 pens are allowed when lines with angled stroke is disabled, while only one when enabled.

## 5.5.2 Screenshot

Go to lacktriangledown ightharpoonup Screenshot, and a capture area pops up on the current page. Adjust the area by tapping and dragging the four corners. The screenshot toolbar pops up on the lower right corner of the area.



Figure 5-8 Screenshot

Table 5-4 Screenshot Toolbar Descriptions

Icon	Description
$\leftarrow$	Exit screenshot.
0	Capture the whole page.
8	Generate QR code from the screenshot, and terminal devices with Internet access or in the same LAN with the Interactive Flat Panel can scan the QR code to download the screenshot.
<b>✓</b>	Save the screenshot in the capture area.

## 5.5.3 Vote Machine

After the tablet is connected to the public network, click **Vote** in the Control Menu. You can choose quick vote or vote according to the set options.

## **Before You Start**

Make sure the device is connected to the network.

#### **Quick Vote**

Step 1 Click **Quick** to select the number of voting options.




Figure 5-9 Quick Vote

Step 2 Configure the following parameters according to the actual needs.

- Anonymous: Vote without name.
- Multiple Selections: Select multiple-options when voting.

Step 3 Click **Generate Vote Code** to vote through scanning the code by mobile phone.




Figure 5-10 Vote by Mobile Phone

Step 4 Click View Vote Results to end voting and check the details.

Step 5 Optional: Click **Scan to Download** to download the voting results through mobile phone.

#### **Advanced Vote**

Step 1 Click **Advanced** to set the vote through scanning QR code by mobile phone with Internet access or in the same LAN with the Interactive Flat Panel.




Figure 5-11 Advanced Vote

Step 2 Configure the following parameters according to the actual needs.

- Vote Theme/Vote Options: Custom configuration.
- Anonymous: Vote without name.
- Multiple Selections: Select multiple-options when voting.

Step 3 Click **Launch Vote** to vote through scanning code by mobile phone.

Step 4 Click View Vote Results to end voting and check the details.

Step 5 Optional: Click Scan to Download to download the voting results through mobile phone.

## 5.5.4 Random Select

In the classroom, you can initiate lucky draw or randomly select a student to answer questions.

#### Steps

Step 1 Go to lacktriangle  $\rightarrow$  Random Select, and set the number of options. Click Next.



Figure 5-12 Set Number of Options

Step 2 Click to start spinning the lucky wheel, and click again to stop. Then you will see the randomly selected option.




Figure 5-13 Lucky Wheel

**i** Note

Tap **Settings**, and you can edit the name of options.




Figure 5-14 Selected Option

# 5.6 Camera Functions

## 5.6.1 Camera

Click Camera to take a photo or video.




Figure 5-15 Camera

Table 5-5 Screenshot Toolbar Descriptions

Icon	Description
	Exit camera.
•	Delay taking pictures according to the selected delay time.
<b>O</b>	Take photos. You can import the photos to the whiteboard or save them to your phone.
	After the mobile phone and the device are connected to the same LAN, you can control the camera to take photos by scanning the code.

# 5.6.2 Video




Figure 5-16 Video

Table 5-6 Screenshot Toolbar Descriptions

Icon	Description
€	Exit video.
<b>(</b> )	Start recording.

## 5.6.3 Settings

Click **Settings** to configure the following parameters.




Figure 5-17 Set Camera

#### **Camera Switch:**

Click oswitch camera between the system camera and the external camera.

When switching to an external camera, tap in the system bar and then adjust **Camera Settings**.




Figure 5-18 External Camera Settings



Figure 5-19 External Camera Settings Options

### **Intelligent Application:**

 AutoFraming: After this function is enabled, the camera will automatically adjust and display the detected face in the middle of the screen. You can choose the sensitivity from three options: low, middle and high.




Figure 5-20 AutoFraming Sensitivity Options

• **Speaker Follow**: After this function is enabled, the camera will automatically follow the detected speaker and display the speaker in the middle of the screen. You can choose the sensitivity from three options: low, middle and high.



Figure 5-21 Speaker Follow Sensitivity Options

## **Basic Settings**

- Image Mode: Click to select image mode, including Standard, Vivid, and Back-Lighting.
- FOV: Click to select Wide-Angle Mode or Center Mode.
- Screen Mirroring: After this function is enabled, the camera will reverse the image.

# **Chapter 6 System Settings**

The screen displays the main page after the device is turned on. Slide the screen to the left of right to view applications, device status, and help documents.

# 6.1 Network Settings

The network status is displayed at the bottom of the screen.

Table 6-1 Different Network Status

Icon	Description
딛	Connected to a wired network.
ি	Connected to a wireless network.
€	No network connected.

## 6.1.1 Wired Network Settings

Step 1 Go to Settings  $\rightarrow$  Network  $\rightarrow$  Wired Network.

Step 2 Enable Wired Network.




Figure 6-1 Wired Network Settings

Step 3 Optional: Tap to enable Proxy or Static IP.

## **Proxy Settings**

When proxy enabled, you need to set **Proxy Host** and **Port No.**, and set the URLs that do not use the proxy.




Figure 6-2 Proxy Settings

#### **Static IP Settings**

When static IP enabled, you need to set network parameters, such as IP Address, Gateway, Subnet Mask, DNS1, and DNS2.




Figure 6-3 Static IP Settings

## 6.1.2 Wireless Network Settings

Step 1 Go to Settings  $\rightarrow$  Network  $\rightarrow$  Wireless Network.

Step 2 Enable WLAN, and you can add a new network or connect to an available network.

#### **Connect to Available Networks**

- Tap the desired network in the available network list, and enter the password to connect.
- Tap **Connect**, and network information page pops up. Tap **Clear Network** to delete the information of the selected network. Tap **Cancel** to exit the page.




Figure 6-4 Wireless Network Information

#### **Add Other Networks**

Step 1 Tap Add Other Networks.

Step 2 Enter Wi-Fi name and select Security.




Figure 6-5 Add Other Network

Step 3 Optional: Check **Display Advanced Settings** to select proxy and network IP type.

Step 4 Tap **Connect** to connect the device to the added wireless network.

# 6.1.3 WLAN Hotspot Settings

When the device is connected to the wired network, it can provide wireless network for other devices with WLAN hotspot enabled.

Step 1 Go to **Settings**  $\rightarrow$  **Network**  $\rightarrow$  **Hotspot**.

Step 2 Enable **Portable WLAN Hotspot**.

**Hotspot Isolation:** After enabling hotspot isolation, even if the device is connected to the LAN, it cannot access resources such as websites in the LAN.

Step 3 Set parameters in the pop-up page.




Figure 6-6 Hotspot Settings



If the device supports both 2.4 GHz and 5 GHz, set 5 GHz as **AP Frequency**, and recommended channels as **AP Channel** for better experience functions such as wireless screen mirroring.

# 6.2 Display Settings

Go to **Settings** → **Display** to adjust parameters, such as brightness and sleeping time.




Figure 6-7 Display Settings

#### **Auto Brightness**

The device can adjust brightness according to the environment automatically when enabled.

### **Brightness Parameter**

Slide the slider to adjust the brightness of the screen.

#### **Bluelight Filter**

Enable the function to protect your eyes by filtering blue light.

## **Color Temperature**

Tap to select **Highlight**, **Normal**, **Cool Color** and **Warm Color** mode.

#### **Theme**

Set the device theme. Tap **Settings** to select a desired theme, and tap **Apply**.

#### Wallpaper

Tap **Wallpaper** to select a desired picture from wallpaper library or the system picture library as wallpaper, or restore to the default wallpaper.

#### Sleep

Set an inactivity period for sleep mode.

#### Screensaver

Set an inactivity period for enabling screensaver.

#### **Screensaver Configuration**

Tap to select a screensaver picture in the pop-up page, and tap **Live View** to preview the effect. Tap **Apply** to set the selected picture as the screensaver. The screensaver can also be customized.



You can add new screensaver pictures in **Screensaver Configuration** by tapping +.

# 6.3 Audio Settings

Step 1 Go to **Settings**  $\rightarrow$  **Audio** to set audio parameters.

Step 2 Adjust the **Volume** value.

Step 3 (Optional) Select Audio Mode and Noise Reduction Level.

Step 4 (Optional) **Sound Collect Area**: The range of the area where you want sound to be collected from will change in real time according to the configuration.




Figure 6-8 Sound Collect Area

## 6.4 Language and Input Settings

- Step 1 Go to **Settings**  $\rightarrow$  **Language & Input**.
- Step 2 Tap Language to select the desired language.
- Step 3 Tap Input Method to select the desired input method.



Figure 6-9 Language and Input Settings

## 6.5 Date and Time Settings

Step 1 Go Settings  $\rightarrow$  Date & Time.




Figure 6-10 Date and Time Settings

Step 2 Enable Time Sync.

Step 3 Tap **Select Time Zone** to select the region.

Step 4 (Optional) Enable **24-Hour Format** to display the time in 24-hour format.

Step 5 (Optional) Select **Time Format**.

Note

If **Time Sync** is disabled, you can set date and time manually.

## 6.6 Application Management

Step 1 Go to **Settings**  $\rightarrow$  **Application Management**.

Step 2 Tap the desired application to check details.




Figure 6-11 Application Details



- The built-in applications cannot be uninstalled. You can tap the icon in **Application Details** to open the application.
- After the third-party application is installed, the 4K display can be enabled (take effect after the equipment is restarted).
- Step 3 Enable **Auto-Launch**. The selected application will be started automatically when the device is powered on.
- Step 4 (Optional) Select the window style (portrait/landscape mode). When you open an application in window mode, the window will display the corresponding style.

### 6.7 Bluetooth

The remote control, audio, keyboard, etc. can be connected through Bluetooth, and file transfer can also be performed.

Enable Bluetooth to search the available devices nearby, and tap the desired one to connect.

## 6.8 Auxiliary Functions

## 6.8.1 Intelligent Temperature Control

The device monitors inner temperature in real time. When the temperature exceeds the set warning or alarming temperature limit, the device will display prompt messages for you to take measures in a timely manner.

### Step 1 Go to Settings $\rightarrow$ Auxiliary Functions $\rightarrow$ Temperature Control.




Figure 6-12 Intelligent Temperature Control

### Step 2 Enable Temperature Detection.

Step 3 Slide to set Warning Temperature and Alarming Temperature.



When the temperature exceeds the set alarming temperature limit, turn off the device as indicated by the pop-up message.

### 6.8.2 Smart Remote Control

You can control the device through the remote control (optional).

Go to **Settings** → **Auxiliary Functions** → **Smart Remote Control**, enter the remote control configuration page.

<u>Remote Control Combination Key Instructions (available when firmware version is V3.5.0101)</u> **Quick Menu Usage Instructions:** 

- After connecting the Bluetooth remote, press and hold the remote's Menu key to bring up the Quick Function Menu.
- Press the remote's Up/Down buttons will move the blue focus frame up or down.
  - If pressing **Up/Down** doesn't move the blue frame in the Quick Menu, it may be because the blue focus frame is simultaneously in "all programs" in the bottom bar.
     In this case, press **Menu** once more to bring the focus back to the Quick Menu, then the Up/Down buttons will control it.
- The Quick Menu works with both the Bluetooth remote control and touch input. Clicking the corresponding option will take you to the corresponding function. Exiting the menu: Press **Back** on the remote or tapping outside the quick menu.

### Quick Menu Functions (Press OK with blue focus frame on option to activate):

1. Freeze Screen:

• When the blue frame is focused on "Freeze Screen", press the **OK** button to enter the freeze screen, and press the **Home** button to exit freeze screen mode.

### 2. Black Screen:

o When the blue frame is focused on "Black Screen", press the **OK** button to enter the black screen mode, and press **OK** again or tap anywhere on the screen to exit.

### 3. Touch Capability:

- o Press **OK** to **turn off** the touch capability.
- Press **OK** again to **turn on** the touch capability.
- o Alternatively: Tap this button directly to toggle the switch.
- o Ps: After shutdown/restart, touch capability is **enabled (ON)** by default.

### 4. Button Enable (Power Button Lock):

- When the blue frame is focused on "Button Enable", Press **OK** to disable the power button (Power button becomes unresponsive to short or long presses).
- Press **OK** again to enable the power button.
   Ps: After shutdown/restart, the power button is **enabled (ON) by default.**

### 5. Input Select:

- When the blue frame is focused on "Input Select", Press **OK** brings up the Input Source selection menu, then the Quick Menu focus disappears, and the blue focus frame defaults to the first line of the Input Source list.
- Press the remote's **Up/Down** buttons to move the blue focus frame and **OK** to switch to the target input channel.
- o Tap outside the Input Source menu area to hide both it and the Quick Menu.
- o the current channel is indicated by a **blue checkmark** next to it. Input source with an active signal displays in **black text & icons**, while inactive ones show in **grey**.
- o Press **Home** button to exit and return to Android interface.

## 6.9 Advanced Settings

Select **Settings** → **Advanced Settings**. You can set parameters as follows.




Figure 6-13 Advanced Settings

#### E-mail

Set the E-mail address for receiving shared contents from whiteboard.

### **Input Source Settings**

### Startup Input Source

Select the desired input source as the device starts up. You can select a built-in system, or an external input source. The default boot input source is Android. Customize input source names are supported.

### Auto Switch When Connecting Signal Source

If this function is enabled, the system will switch to the newly-connected input source when an external input source is connected.

### Auto Switch When Disconnected from Signal Source

If this function is enabled, the system will switch to the configured input source as the device is disconnected from the external input source.

### **Select Camera**

Select an external camera among those bound to the device.

### **Input Device**

It supports external USB input audio devices, and can select audio input devices from multiple devices.

### **Output Device**

It supports external USB output audio devices, and can select audio output devices from multiple devices.

### **Startup/Shutdown Settings**

### Startup Mode

Select Startup or Standby.

### Scheduled Startup/Shutdown

Set the schedule for startup and shutdown.

### No-signal Shutdown

Set the time for auto-shutdown if no signal is accessible.

### **Device Permission Settings**

#### Disable Wi-Fi

If Wi-Fi is disabled, the device cannot be connected to the wireless network.

### Copy Permission Off

If copying from USB disk is disabled, the device cannot be read from external disks.

### **QR Code Sharing Settings**

Share the content of whiteboard through a QR code scanned by other terminal devices with Internet access or in the same LAN with the Interactive Flat Panel.

### **Wakeup Settings**

#### Wake from Serial Port

If this function is enabled, the device in standby status can be woken up by serial port command.

### Wake from Signal Source

HDMI signal wake-up is enabled by default. When the device is turned off, it can be turned on through HDMI input.



If this function is disabled, the device in standby status can be waken up through the power switch or remote control power switch, and cannot be turned on through the serial port and HDMI.

### **EDID Version**

Supports to select EDID's version.

### **HDMI Output Settings**

Connect the device through HDMI interface to share the contents. You can set the desired resolution, enable HDCP (High-bandwidth Digital Content Protection), and select to play audio on the output device or both devices (Interactive Flat Panel and the output device).




Figure 6-14 HDMI Audio Settings



To enable the HDCP function, the display connected to the flat panel must support the HDCP function.

### **Boot Animation Settings**

- Place the animation file in the root directory of your USB flash drive, and click **Set Boot Animation**. The system will automatically detect the qualified animation file and replace.
- Click Reset Boot Animation to restore to the factory settings.



The boot logo should be in BMP format, and the bit depth of the image is 8. The boot animation file should be in PNG or JPG format.

## 6.10 User Settings

You can add multiple accounts on a shared interactive flat panel, set the sign-in information for each account, share a device with multiple persons, and view their own files, browser favorites, and settings.

Go to **Settings**  $\rightarrow$  **User Settings**, and enable **Multi-User Settings**, you can manage accounts of the device.




Figure 6-15 User Settings

Table 6-2 Icon Description

Icon	Description
+ Add Account	Add an account.
	Set account name within 64 characters.
	Set password within 4 to 6 digits.
<b>=</b>	Switch accounts. Enter the password of the corresponding account to login.
_	Edit your account's information.
<del>6</del>	Edit your account's password.
Ū	Delete the account. The data of this account will be deleted from the device as well.

### **Unlock USB Flash Disk**

Tap to set the login method with USB Flash Disk. After configuration, you can directly log in by inserting the USB flash drive.

#### Steps

Step 1 Tap Unlocking USB Flash Disk.

Step 2 Enter the login password, and then insert one USB flash drive.

 $\bigcap$ i Note

- If a normal user forgets the password, contact the administrator.
- If the administrator forgets the password, try to unlock through a USB flash disk.
- Administrator login supports setting login method as login with password or not.

Step 3 Click **Generate File**. The device will automatically generate the unlocking file in the USB flash drive. After the file is generated, you can log in easily by directly inserting the USB flash drive next time.



Figure 6-16 Link the Unlocking USB Flash Drive

### 6.11 Device Information

Go to **Settings**  $\rightarrow$  **About** to check the device information. The device name is customizable, and you can restore the device to the default settings.



All the data will be lost if the settings are restored to the default status.

## 6.12 Negative Screens

Slide from the left side of the screen to the right to call up the negative screens, where you can view the device status and system help.



Figure 6-17 Negative Screens

# **Chapter 7 Intelligent Applications**

### 7.1 FileBrowser

Tap **FileBrowser** on the main page. All the files under the current directory are shown by default. Tap **Image**, **Doc**, **A/V**, or **Installation Package** to view specified files.

Icons are described as follows.




Figure 7-1 File Management

Table 7-1 Descriptions of File Management Icons

Icon	Description	Icon	Description
Back/Forward	Go to the previous/next page.	Create	Create a new folder.
Grid/List	View the files in grid or list mode.	Sort	Change the file order.
Edit	Edit the files.		

Click to edit documents. More functions are described as follows.




Figure 7-2 Edit the Files

Table 7-2 Descriptions of Editing Icons

Icon	Description	Icon	Description
Select All	Select all the files.	Сору То	Copy the selected file(s) to another folder.
Move To	Move the selected file(s) to another folder.	Delete	Delete the selected file(s).
Share	Share the selected file(s).		

## **i** Note

Press and hold the file to perform other operations.

### 7.2 Browser

Connect the device to the Internet, and tap **Browser**. Enter URL in the address bar to view texts, pictures, audios and videos on the Internet.

### 7.3 Whiteboard

Whiteboard is an editing software that integrates functions such as touch writing, image insertion, and content sharing. Users can add boards with different backgrounds for touch writing, erasing,

and page switching operations. It supports importing and editing images, and after the whiteboard content is completed, it can be saved locally or shared via email.

### 7.3.1 Toolbar Basic Operation

By using the toolbar, you can write, erase, select, restore/undo, and take other operations on the whiteboard.



Figure 7-3 Toolbar

#### Write

The writing function is used to write on a whiteboard. Tap on the toolbar to adjust parameters such as brush type, color, thickness, etc.



Figure 7-4 Set Wrtiting Parameters

#### **Erase**

The erase function is used to erase the content written on the whiteboard. Tap on the toolbar to select the following actions:

- Partial Erase: Tap ☑, click and drag the eraser on the area that needs to be deleted, and the content of the covered area will be deleted. Supports sliding the slider to adjust the size of the eraser.
- Circle Erase: Tap to circle the area that needs to be deleted. The content of the trajectory touched in the circle area will be deleted.
- Erase All: Tap 🗖 to clear all written content on the current whiteboard page.
- Gesture Erasing: When your palm, or back of hand contact with the screen, you can perform large-scale erasing operations.

### **Circle Selection**

Tap  $\square$  on the toolbar to circle any shaped area ( $\square$ ) or rectangular area ( $\square$ ) and edit the content in the area.

- 🗅: Lock the content within the selected area. Long press on the area or tap 🔼 to unlock.

## **i** Note

- Support resizing, moving, and rotating the content in the selected area.
- Tap outside the selected area to cancel the area selection.

### **Undo or Redo**

When accidentally writing or erasing, the undo tool can be used to undo your operation.

- Elick to undo the last action;
- Click to redo the previous action.

### 7.3.2 More Tools

Tap on the toolbar to call up the following tools:




Figure 7-5 More Tools

Table 7-3 Tools Description

Icon	Name	Description
	Shape	Insert 2D and 3D shapes.
***	Ruler and Compass	Use a ruler, protractor, square, or compass. Drag to adjust size and angle.
	Table	<ul> <li>Insert a table.</li> <li>Long press the table to add/delete rows or columns;</li> <li>Drag the table to move or resize it;</li> </ul>
		<ul> <li>Tap the table to choose to modify the color of the content written in the table.</li> </ul>
		• Click and enable <b>Shape Recognition</b> . You can draw horizontal and vertical lines to trigger table recognition.
÷	Flow Chart	<ul> <li>You can select different shapes and lines to draw a flowchart on the whiteboard.</li> <li>Click to fix the shape bar.</li> </ul>
D <del></del>	Tactic Board	Tap to create a basketball tactic board.
<b>&gt;</b>	Note	Insert a note. Support moving, resizing, copying notes, and changing the color of notes.
•	Stopwatch	Open the stopwatch.
<b>O</b>	Countdown	Open the countdown.
<b>*</b>	Voting Machine	Open the voter machine.
==	Calculator	Open the calculator.
~	Insert Picture	After inserting a picture, you can lock, resize, move, rotate, delete the picture, and modify the color of the content written in the area.
	Open Video	Play video files.
	Open Document	Open documents in PPT, PPTX, DOC, DOCX, and PDF for display.
=	Library	Tap to search images and videos and insert.
	Browser	Call up the browser on the side of the whiteboard.

## **i** Note

You can click to bring up the sidebar.




Figure 7-6 Tools Sidebar

You can draw a line on any corner of the shape or table to expand.




Figure 7-7 Expand Shape and Table

• Library and Browser are only supported when the Whiteboard application is full screen.

### **Tactic Board**

- 1) Tap to create a tactic board. Move to change the player's position.
- 2) Enable on the lower-right corner to draw a line on a player. Line types will be prompted and you can select one.



Figure 7-8 Select Line Type

3) Click to select the number of players. Click to select a tactic.



Figure 7-9 Select Tactic

- 4) Draw your own tactic on the board, and click to name the tactic and save. You can find your own saved tactic in
- 5) Click ? on the lower-left corner to see the function guide.



Figure 7-10 Function Guide

## 7.3.3 Manage Whiteboard

You can create a new whiteboard, switch whiteboards, and delete whiteboards.

Table 7-4 Function Description

Function	Description
Add Whiteboard	Tap on the bottom right corner to add a whiteboard page.
Switch Whiteboard	Tap (/> to switch the whiteboard page.
Drag Whiteboard	A single whiteboard is infinitely large, and you can drag the whiteboard page up, down, left, right with five fingers to extend writing space.
View Whiteboard	Tap 1/8 on the page number area to display a thumbnail of the whiteboard page. Swipe the thumbnail up and down, and tap a page to jump to the displayed page.
Delete Whiteboard	Tap 1/8 on the page number area and tap on the bottom right corner of the page to delete that page.



All information will be reset after closing the whiteboard.

### 7.3.4 Save Whiteboard

After the whiteboard content is completed, the page can be saved locally on the device for reference or shared with others.

Step 1 Tap on the bottom left of the whiteboard.




Figure 7-11 Save Whiteboard

Step 2 Select a format.

Note

Support saving the board as PNG format images, PDF format documents, or editable VWB format files.

Step 3 (Optional) Edit the name of the board.

Step 4 Tap Save.

### 7.3.5 Share Whiteboard

Users can share whiteboards with others via email or QR code.

### **Share via Email**

Tap on the bottom left of the whiteboard and select **Email**.

**i** Note

Make sure the Email server has been configured before you start.

### **Share Via QR Code**

Tap on the bottom left corner, mobile devices with Internet access or in the same LAN with the Interactive Flat Panel can scan the code to download whiteboard content.



Figure 7-12 Share via QR Code

### 7.3.6 More Functions

Tap on the bottom left corner of the whiteboard to achieve functions such as split-screen writing and dual-color writing.




Figure 7-13 More Functions

### **Split-Screen Writing**

Support whiteboard simultaneous writing on split screens.

- Tap 00 or witch between two or three screens.

## **i** Note

When changing the number of split screens and exiting split-screen writing, the current content will not be saved.

### **Dual-Color Writing**

After enabling, different colors can be selected for writing on the tip and tail of the writing pen.



- Long press the stroke support for adjusting the pen's threshold.
- You can click ? to see the function guide.

### **Finger Scale**

After enabling, you can use fingers to zoom in/out the page. Click ? to see the function guide.

### **Multi-Touch Writing**

After enabling, the whiteboard supports multi finger touch, meaning that multiple fingers can simultaneously edit the whiteboard.

### **Text Recognition**

After enabling, the whiteboard can recognize the drawn text and correct it to the regular text.

### **Shape Recognition**

After enabling, the whiteboard can recognize the drawn graphics and correct them to the regular graphics.



- The recognizable shapes include circles, triangles, rectangles, and lines.
- Text recognition and shape recognition do not support simultaneous activation.

#### **Menu Position**

After enabling, the menu on the left and page numbers on the right of the whiteboard are swapped for easy access to the function icons and menus.

### **Background**

Set the background and shading of the whiteboard, and you can customize the whiteboard background style as needed.

### Open

Open the whiteboard file saved as a VWB format for editing again.

#### **About**

View the current version and open source agreement.

### 7.4 WonderCastServer

### 7.4.1 NFC Screen Mirroring

An Android phone with NFC can mirror its screen to the interactive flat panel (only when the mobile phone has been installed with WonderCast and enabled NFC).

- Step 1 Connect the mobile phone and the Display to the same LAN, or connect the mobile phone to the Display's hotspot.
- Step 2 Stick the back of your mobile phone to the NFC area on the interactive flat panel, and the screen can be mirrored after the prompt appears on your phone.

## 7.4.2 Other Screen Mirroring

You can mirror the screen of your PC or mobile phone on the Interactive Flat Panel, or control the Flat Panel through your PC or phone. Please scan the following QR code for more details about WonderCastServer.



Figure 7-14 WonderCastServer

## 7.5 System Pre-Installed Applications

The following table briefly describes the applications pre-installed in the system. Refer to the help document of desired application, to get more details.



The system pre-installed applications vary from different device types.

Table 7-5 Introduction of System Pre-Installed Applications

Application	Introduction
Whiteboard	It is applied to draw and write. You can use it to save, move, zoom in, zoom out, delete, and download the contents.
FileBrowser	Manage your files.
Browser	After the device is connected to the network, it can browse internet information through a browser.
Gallery	It is used for viewing pictures in SD card and USB disk.
Upgrade	It provides remote upgrade and local upgrade, and upgrade of local components.
WonderCastServer	An application used to connect flat panel, mobile phone, or PC for screen mirroring.
Camera	It is used for taking picture by camera.
Ark	It is used for docking with the centralized control platform, so that devices can be remotely managed through the platform, such as sending files and upgrading remotely.

## Interactive Flat Panel • User Manual

It is used for releasing programs and schedules to the digital signage.
It is a marketplace for devices to find and download apps, games, books, movies, and other forms of entertainment.
It provides detailed information about geographical regions and sites worldwide.
It is a service that backs up your entire photo and video library for free.
It is a cloud storage service that lets you upload, sync, and share files online.
It is a platform that combines streaming apps, live TV, and personalized recommendations in one unified user interface.
It is a free web browser developed by Google, used for accessing web pages on the internet.
It is a free service provided by Google that enables users to send and receive e-mail over the Internet.
It is a search engine provided by Google.
It is a video conferencing service.
It is a social media platform and website for sharing videos.
It is a music streaming service from Google.
It is a time management and scheduling tool created by Google.

# Chapter 8 Appendix A FAQs

Question	Cause and Solution
Why do the condensations appear frequently on the screen?	Tempered glass is installed on the outer screen to provide protection. There is a gap between the screen and the tempered glass for air convection. The main reason is that there is a temperature difference between the screen and the outside. Hot air condenses on the glass surface at a lower temperature, which results in condensations. Condensations will evaporate after the device starts up and will not affect the use of the device.
Why there is no sound coming from my laptop after connection?	If only audio cable is accessed, both audio output and image output will be unavailable.  • Access HDMI cable.  • Select the device as the audio output device in Windows.
Why does the screen get hot after a period of use?	Screen temperature rise is caused by heat dissipation and is completely normal. Our heat dissipation design is industrial-leading and is the formulator of the industry standards, which is in accordance with the national health standard.
Does long-time use damage the eyes?	The recognition of flicker by human eyes is 50Hz. If the frequency is lower than 50Hz, then the flicker will be recognized and cause eye muscles fatigue. We use 60Hz LCD screen, human eyes will not recognize the flicker of the screen. Compared with other products of the same kind, it can reduce eye fatigue to a large extent.
Why there is no image in screen nor sound coming from the device?	<ul> <li>Check if the power cable is connected.</li> <li>Check if the socket works normally.</li> <li>Check if the power switch is turned on.</li> </ul>
Why does the device HDMI channel have no input signal?	<ul> <li>Check if the input source works normally.</li> <li>Change HDMI interface or cable.</li> <li>If PC is accessed, set HDMI output on your PC.</li> </ul>
Why is wired network unstable?	Try to disable the auto network detection option.

