

Title:	DS-PD1-SMK-W How to reset and connect	Version:	v1.0	Date:	19/12/2019
Product:	Alarm	Page:	1 of 4		



DS-PD1-SMK-W

How to reset and connect

(2019-12-19)

Wireless smoke detector parameters

RF transmission distance	800m (open area)
Alarm sound pressure	≥ 85 dB (1m from the front)
Working Temperature	-10°C ~ +55°C
Working Humidity	$\leq 95\%$ RH
Dimensions (mm)	$\Phi 90 \times 32$
Weight (g)	111.5

Wireless smoke detector appearance



How to power the wireless smoke detector

1. Powered by CR123A battery




Title:	DS-PD1-SMK-W How to reset and connect	Version:	v1.0	Date:	19/12/2019
Product:	Alarm	Page:	2 of 4		




How to add wireless smoke detector

1. Click the wireless security control panel function button



2. Power on the wireless smoke detector, then Click the learn button



3. Wireless security control panel will say 'The smoke detector is added to zone 1', the addition is successful
4. Click wireless security control panel function button again to finish the adding mode

How to reset the wireless smoke detector

1. Hold down learn button of wireless smoke detector, and then power on the device

Title:	DS-PD1-SMK-W How to reset and connect	Version:	v1.0	Date:	19/12/2019
Product:	Alarm	Page:	3 of 4		



Learn button

2. Hold down the button, after red light flash 3 times, means reset successfully, as below



Title:	DS-PD1-SMK-W How to reset and connect	Version:	v1.0	Date:	19/12/2019
Product:	Alarm	Page:	4 of 4		



First Choice for Security Professionals
***HIK*VISION Technical Support**