

<b>Title:</b>	DS-PD1-WL-W How to reset and connect	<b>Version:</b>	v1.0	<b>Date:</b>	19/12/2019
<b>Product:</b>	Alarm	<b>Page:</b>	1 of 4		



## DS-PD1-WL-W

### How to reset and connect

(2019-12-19)

#### Wireless water leak detector parameters

RF transmission distance	300m (open area)
Tamper Switch	YES
Detection method	Touch
Working Temperature	-10°C ~ +55°C
Working Humidity	≤95%RH
Dimensions (mm)	73 x 52 x 21

#### Wireless water leak detector appearance



#### How to power the wireless water leak detector

1. Powered by CR2450 battery




<b>Title:</b>	DS-PD1-WL-W How to reset and connect	<b>Version:</b>	v1.0	<b>Date:</b>	19/12/2019
<b>Product:</b>	Alarm	<b>Page:</b>	2 of 4		



## How to add wireless water leak detector

1. Click the wireless security control panel function button




2. Power on the wireless water leak detector, then Click the learn button



3. Wireless security control panel will say 'The water leak detector is added to zone 1', the addition is successful
4. Click wireless security control panel function button again to finish the adding mode

## How to reset the wireless water leak detector

1. Hold down learn button of wireless water leak detector, and then power on the device



2. Hold down the button, after red light flash 3 times, means reset successfully, as below

<b>Title:</b>	DS-PD1-WL-W How to reset and connect	<b>Version:</b>	v1.0	<b>Date:</b>	19/12/2019
<b>Product:</b>	Alarm	<b>Page:</b>	3 of 4		

**HIKVISION**



<b>Title:</b>	DS-PD1-WL-W How to reset and connect	<b>Version:</b>	v1.0	<b>Date:</b>	19/12/2019
<b>Product:</b>	Alarm	<b>Page:</b>	4 of 4		



**First Choice for Security Professionals**  
***HIK*VISION Technical Support**