

● HOW TO

Unbind indoor station from Hik-Connect Account on **local GUI**



Indoor station could be unbound from Hik-Connect account via the local GUI by **self-service**.


Support models/version: Above version V2.2.0 (Not include DS-KH9310-WTE1 and DS-KH9510-WTE1)

Step 1: Ensure the device online


Before we unbind the Hik-Connect account, please make sure:

1. Device is connected to the Internet with LAN cable or WIFI.
2. The Hik-Connect Server Status shows Connected.

After connect successfully, the device status will show Connected.




Pic 1. Connect WLAN




Pic 2. Connected status

Step 2: Unbind via GUI


1. Go to **Advanced Settings > Configuration** page, enter the device password.
2. Turn to **System Maintenance** page, tap **Unlink APP Account**, the device will be unbound.




Pic 3. Enter Configuration page



Pic 4. System Maintenance page



Pic 5. Unlinking



Pic 6. Unlink successful